

# BASKET GUIDE

## EL BANDIDO

When using baskets in your El Bandido Oven, always place the basket on top of the closed panini press. Please refer to the images below for guidance.



The panini press is set to the open position by default. To close it, pull the lever on the outer right side of the oven forward. Close the press when you need to place a basket on top and do not require the press for cooking.



**OPEN**



**CLOSED**