


i3 and i5



To access INFO MODE, press the Info key when the oven is either off or cooling down.
To toggle between Info screen 1 and 2, press the Up or Down key.




View From Info Screen 1

- Serial number
- Software version
- Menu part number and revision
- Last temperature selected to cook
- Current electrical compartment temperature
- Operating voltage (US/Canada only)

From Info Screen 1

	Press
Cook Counts	R1
Total Cook Time	R1
Total Magnetron Time	R1
Total "Oven On" Time	R1
Fault Log	R3
Service Phone Numbers	R4



From Info Screen 2

	Press	Keycode
Access TEST MODE	L1	9-4-2-8 and ENTER
Access "Options" Screen	L2	9-4-2-8 and ENTER
Change Display Language*	L3	
Set Date and Time	L4	
Increase/Decrease Sound Volume	L5	
Access "Load Menu" Screen	R1	
Turn F2 Alarm On/Off	R2	

* Not available on all models.

Feature On/Off

	Press from Options Screen
Adjust Time	L1
Cook More	L2
Edit Mode	L3
Load Menu	L4
Demo Mode	L5
Network Setup	R1
Oven Type: i3 or i5	R5